



NOTE – A blower is an air mover it moves air from the inlet to discharge the blower itself does not create any vacuum it is the restricitions within the system pipework and the system that creates the vacuum.